



U018 Series  
(sold separately)



## Series 4000-R

Compact Modbus Power and Energy Meter  
For Use Only With U018 Series Rope CTs

### Product Overview

The Series 4000-R DIN rail meter provides a solution for measuring energy data with a single device. Inputs include control power, CT, and 3-phase voltage. The Series 4000-R supports multiple output options, including solid state relay contacts, Modbus, and pulse. The LCD screen on the faceplate allows instant output viewing. Series 4000-R meters include built-in CT integrators and CT power supplies. They work only with U018 Series rope style CTs.

The meter is housed in a plastic enclosure suitable for installation on T35 DIN rail according to EN50022. The Series 4000-R can be mounted with any orientation over the entire ambient temperature range, either on a DIN rail or in a panel. The meter is not sensitive to CT orientation to reduce installation errors.

### Product Identification

Series 4000-R Unidirectional metering, Modbus full data set, pulse and alarm outputs. For use only with U018 rope style CTs.

### Specifications

#### MEASUREMENT ACCURACY

<b>Real Power and Energy</b>	IEC 62053-22 Class 0.5S, ANSI C12.20 0.5%
<b>Reactive Power and Energy</b>	IEC 62053-23 Class 2, 2%
<b>Current</b>	0.4% (+0.015% per °C deviation from 25°C) from 5% to 100% of range; 0.8% (+0.015% per °C deviation from 25°C) from 1% to 5% of range
<b>Voltage</b>	0.4% (+0.015% per °C deviation from 25°C) from 90V <sub>L-N</sub> to 600VAC <sub>L-L</sub>
<b>Sample Rate</b>	2520 samples per second
<b>Data Update Rate</b>	1 sec
<b>Type of Measurement</b>	True RMS up to the 21st harmonic 60 Hz; One to three phase AC system

#### INPUT VOLTAGE CHARACTERISTICS

<b>Measured AC Voltage</b>	Minimum 90V <sub>L-N</sub> (156V <sub>L-L</sub> ) for stated accuracy; UL Maximums: 600V <sub>L-L</sub> (347V <sub>L-N</sub> ) CE Maximum: 300V <sub>L-N</sub>
<b>Metering Over-Range</b>	+20%
<b>Impedance</b>	2.5 MΩ <sub>L-N</sub> / 5 MΩ <sub>L-L</sub>
<b>Frequency Range</b>	45 to 65 Hz

#### INPUT CURRENT CHARACTERISTICS

<b>CT Scaling</b>	20A to 5000A
<b>Measurement Input Range</b>	U018 series rope style CTs only (CTs must be rated for connection to Class 1 voltage inputs)

**⚡ ⚠ DANGER**

**HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

- Turn off all power supplying equipment before working on or inside the equipment.
- Follow safe electrical work practices. See NFPA 70E in the USA, or applicable local codes.
- This equipment must only be installed and serviced by qualified electrical personnel.
- Read, understand and follow the instructions before installing this product.
- Product may use multiple voltage/power sources. Be sure all sources of power have been disconnected before servicing.
- Use a properly rated voltage sensing device to confirm power is off.
- DO NOT DEPEND ON THIS PRODUCT FOR VOLTAGE INDICATION
- Only install this product on insulated conductors.

**Failure to follow these instructions will result in death or serious injury.**

A qualified person is one who has skills and knowledge related to the construction and operation of this electrical equipment and the installation, and has received safety training to recognize and avoid the hazards involved. NEC2011 Article 100  
No responsibility is assumed by Leviton for any consequences arising out of the use of this material.

Control system design must consider the potential failure modes of control paths and, for certain critical control functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and over-travel stop.

**⚠ WARNING**

**LOSS OF CONTROL**

- Assure that the system will reach a safe state during and after a control path failure.
- Separate or redundant control paths must be provided for critical control functions.
- Test the effect of transmission delays or failures of communication links.<sup>1</sup>
- Each implementation of equipment using communication links must be individually and thoroughly tested for proper operation before placing it in service.

**Failure to follow these instructions may cause injury, death or equipment damage.**

<sup>1</sup>For additional information about anticipated transmission delays or failures of the link, refer to NEMA ICS 1.1 (latest edition), *Safety Guidelines for the Application, Installation, and Maintenance of Solid-State Control* or its equivalent in your specific country, language, and/or location.

**CAUTION**

- This product is not intended for life or safety applications.
- Do not install this product in hazardous or classified locations.
- The installer is responsible for conformance to all applicable codes.
- Mount this product inside a suitable fire and electrical enclosure.

#### FCC PART 15 INFORMATION

NOTE: This equipment has been tested by the manufacturer and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Modifications to this product without the express authorization of the manufacturer nullify this statement.

For use in a Pollution Degree 2 or better environment only. A Pollution Degree 2 environment must control conductive pollution and the possibility of condensation or high humidity. Consider the enclosure, the correct use of ventilation, thermal properties of the equipment, and the relationship with the environment. Installation category: CAT II or CAT III. Provide a disconnect device to disconnect the meter from the supply source. Place this device in close proximity to the equipment and within easy reach of the operator, and mark it as the disconnecting device. The disconnecting device shall meet the relevant requirements of IEC 60947-1 and IEC 60947-3 and shall be suitable for the application. In the US and Canada, disconnecting fuse holders can be used. Provide overcurrent protection and disconnecting device for supply conductors with approved current limiting devices suitable for protecting the wiring. If the equipment is used in a manner not specified by the manufacturer, the protection provided by the device may be impaired.


<b>CONTROL POWER</b>	
<b>AC</b>	5VA max.; 90V min. UL Maximums: $600V_{L-L}$ ( $347 V_{L-N}$ ) CE Maximum: $300V_{L-N}$
<b>DC*</b>	3 W max.; UL and CE: 125 to 300VDC
<b>Ride Through Time</b>	100 msec at 120VAC
<b>OUTPUT</b>	
<b>Alarm Contacts</b>	N.C., static output (30VAC/DC, 100mA max. @ 25°C, derate 0.56mA per °C above 25°C)
<b>Real Energy Pulse Contacts</b>	N.O., static output (30VAC/DC, 100mA max. @ 25°C, derate 0.56mA per °C above 25°C)
<b>RS-485 Port</b>	2-wire, 1200 to 38400 baud, Modbus RTU
<b>MECHANICAL CHARACTERISTICS</b>	
<b>Weight</b>	0.62 lb (0.28 kg)
<b>IP Degree of Protection (IEC 60529)</b>	IP40 front display; IP20 Meter
<b>Display Characteristics</b>	Back-lit blue LCD
<b>Terminal Block Screw Torque</b>	0.37 to 0.44 ft-lb (0.5 to 0.6 N·m)
<b>Terminal Block Wire Size</b>	24 to 14 AWG (0.13 to 2.08 mm <sup>2</sup> )
<b>Rail</b>	T35 (35mm) DIN Rail per EN50022
<b>OPERATING CONDITIONS</b>	
<b>Operating Temperature Range</b>	-30° to 70°C (22° to 158°F)
<b>Storage Temperature Range</b>	-40° to 85°C (-40° to 185°F)
<b>Humidity Range</b>	<95% RH noncondensing
<b>Altitude of Operation</b>	3000 m
<b>COMPLIANCE INFORMATION</b>	
<b>US and Canada</b>	CAT III, Pollution degree 2; for distribution systems up to $347V_{L-N}$ / $600VAC_{L-L}$
<b>CE</b>	CAT III, Pollution degree 2; for distribution systems up to $300V_{L-N}$
<b>Dielectric Withstand</b>	Per UL 508, EN61010
<b>Conducted and Radiated Emissions</b>	FCC part 15 Class B, EN55011/EN61000 Class B (residential and light industrial)
<b>Conducted and Radiated Immunity</b>	EN61000 Class A (heavy industrial)
<b>US and Canada (cULus)</b>	UL508 (open type device)/CSA 22.2 No. 14-05
<b>Europe (CE)</b>	EN61010-1

\* External DC current limiting is required, see fuse recommendations.


## Table of Contents

Dimensions	4
Data Outputs	4
Product Diagram	5
Display Screen Diagram	5
Installation	6
Supported System Types	7
Wiring Symbols	7
Wiring	8
Control Power	9
Quick Setup Instructions	10
Solid State Output	11
User Interface Menu Abbreviations Defined	11
User Interface for Data Configuration	12
Alert/Reset Information	13
User Interface for Setup	14
RS-485 Communications	16
Standard Modbus Default Settings	17
Modbus Point Map Overview	18
Modbus Point Map	19
Troubleshooting	24
China RoHS Compliance Information (EFUP Table)	24


## Dimensions



*Bottom View (DIN Mount Option)*



*Bottom View (Screw Mount Option)*




## Data Outputs

### **Full Data Set (FDS):**


- Power (kW)
- Energy (kWh)
- Configurable for CT & PT ratios, system type, and passwords
- Diagnostic alerts
- Current: 3-phase average
- Volts: 3-phase average
- Current: by phase
- Volts: by phase Line-Line and Line-Neutral
- Power: Real, Reactive, and Apparent 3-phase total and per phase
- Power Factor: 3-phase average and per phase
- Frequency
- Power Demand: Most Recent and Peak
- Demand Configuration: Fixed, Rolling Block, and External Sync

## Product Diagram




## Display Screen Diagram

LCD Screen:



Buttons:



## Installation


-  **WARNING: TO AVOID FIRE, SHOCK, OR DEATH, disconnect power prior to installation.**
-  **Reinstall any covers that are displaced during the installation before powering the unit.**
-  **Mount the meter in an appropriate electrical enclosure near equipment to be monitored.**

**Do not install on the load side of a Variable Frequency Drive (VFD), aka Variable Speed Drive (VSD) or Adjustable Frequency Drive (AFD).**

The meter can be mounted in two ways: on standard 35 mm DIN rail or screw-mounted to the interior surface of the enclosure.

### A. DIN Rail Mounting


1. Attach the mounting clips to the underside of the housing by sliding them into the slots from the inside. The stopping pegs must face the housing, and the outside edge of the clip must be flush with the outside edge of the housing.
2. Snap the clips onto the DIN rail. See the diagram of the underside of the housing (below).



3. To reduce horizontal shifting across the DIN rail, use two end stop clips.

### B. Screw Mounting

1. Attach the mounting clips to the underside of the housing by sliding them into the slots from the outside. The stopping pegs must face the housing, and the screw hole must be exposed on the outside of the housing.
2. Use three #8 screws (not supplied) to mount the meter to the inside of the enclosure. See the diagram of the underside of the housing (below).



## Supported System Types

The meter has a number of different possible system wiring configurations (see Wiring section). To configure the meter, set the System Type via the User Interface or Modbus register 130. The System Type tells the meter which of its current and voltage inputs are valid, which are to be ignored, and if neutral is connected. Setting the correct System Type prevents unwanted energy accumulation on unused inputs, selects the formula to calculate the Theoretical Maximum System Power, and determines which phase loss algorithm is to be used. The phase loss algorithm is configured as a percent of the Line-to-Line System Voltage (except when in System Type 10) and also calculates the expected Line to Neutral voltages for system types that have Neutral (12 & 40).

Values that are not valid in a particular System Type display as "----" on the User Interface or as QNAN in the Modbus registers.

Number of wires	CTs		Voltage Connections			System Type		Phase Loss Measurements			Wiring Diagram
	Qty	ID	Qty	ID	Type	Modbus Register 130	User Interface: SETUP>S SYS	VLL	VLN	Balance	Diagram number
Single-Phase Wiring											
2	1	A	2	A, N	L-N	10	1L + 1n		AN		1
2	1	A	2	A, B	L-L	11	2L	AB			2
3	2	A, B	3	A, B, N	L-L with N	12	2L + 1n	AB	AN, BN	AN-BN	3
Three-Phase Wiring											
3	3	A, B, C	3	A, B, C	Delta	31	3L	AB, BC, CA		AB-BC-CA	4
4	3	A, B, C	4	A, B, C, N	Grounded Wye	40	3L + 1n	AB, BC, CA	AN, BN, CN	AN-BN-CN & AB-BC-CA	5, 6

## Wiring Symbols

To avoid distortion, use parallel wires for control power and voltage inputs.

The following symbols are used in the wiring diagrams on the following pages.

Symbol	Description
	Voltage Disconnect Switch
	Fuse (installer is responsible for ensuring compliance with local requirements. No fuses are included with the meter.)
	Earth ground
	Current Transducer
	Potential Transformer
	Protection containing a voltage disconnect switch with a fuse or disconnect circuit breaker. The protection device must be rated for the available short-circuit current at the connection point.

### NOTICE

#### RISK OF EQUIPMENT DAMAGE

- This product is designed only for use with U018 series current transducers (CTs).
- DO NOT USE CURRENT OUTPUT (e.g. 5A) CTs ON THIS PRODUCT.

**Failure to follow these instructions can result in equipment damage.**

Wiring


**⚠ WARNING ⚡**

**RISK OF ELECTRIC SHOCK OR PERMANENT EQUIPMENT DAMAGE**  
 CT negative terminals are referenced to the meter's neutral and may be at elevated voltages

- Do not contact meter terminals while the unit is connected
- Do not connect or short other circuits to the CT terminals

**Failure to follow these instructions may cause injury, death or equipment damage.**

1. Squeeze the ribbed sections of the CT connector and pull the rope out of the connector to open.




2. Wrap the rope style CT around the conductor to be monitored.


3. Snap the connector back together securely, ensuring there is no dust or debris in the closure area.

4. Connect the CT output leads to the S4000-R meter inputs according to the following diagrams. The white wire is the X1 lead.


*Diagram 1: 1-Phase Line-to-Neutral 2-Wire*




*Diagram 2: 1-Phase Line-to-Line 2-Wire*



*Diagram 3: 1-Phase Direct Voltage Connection 2 CT*



*Diagram 4: 3-Phase 3-Wire 3 CT no PT*




## Wiring (cont.)

**Diagram 5: 3-Phase 4-Wire Wye Direct Voltage Input**

**Connection 3 CT**


Use System Type 40 (3L + 1n)



**Diagram 6: 3-Phase 4-Wire Wye Connection 3 CT**


**3 PT**

Use System Type 40 (3L + 1n)




## Control Power

**Direct Connect Control Power (Line to Line)**




Line to Line from 90 VAC to 600 VAC (UL). In UL installations the lines may be floating (such as a delta). If any lines are tied to an earth (such as a corner grounded delta), see the Line to Neutral installation limits. In CE compliant installations, the lines must be neutral (earth) referenced at less than 300 VAC<sub>L-N</sub>

**Direct Connect Control Power (Line to Neutral)**




Line to Neutral from 90 VAC to 347 VAC (UL) or 300 VAC (CE)

**Direct Connect Control Power (DC Control Power)**



DC Control Power from 125 VDC to 300 VDC (UL and CE max.)

**Control Power Transformer (CPT) Connection**



The Control Power Transformer may be wired L-N or L-L. Output to meet meter input requirements

### Fuse Recommendations

Keep the fuses close to the power source (obey local and national code requirements).

For selecting fuses and circuit breakers, use the following criteria:

- Select current interrupt capacity based on the installation category and fault current capability.
- Select over-current protection with a time delay.
- Select a voltage rating sufficient for the input voltage applied.
- Provide overcurrent protection and disconnecting means to protect the wiring. For DC installations, provide external circuit protection. Suggested: 0.5 A, time delay fuses.
- The earth connection (G) is required for electromagnetic compatibility (EMC) and is not a protective earth ground.

## Quick Setup Instructions


These instructions assume the meter is set to factory defaults. If it has been previously configured, all optional values should be checked.

1. Press the  or  button repeatedly until **SETUP** screen appears.
2.  to the **PASWD** screen.
3.  through the digits. Use the  or  buttons to select the password (the default is 00000). Exit the screen to the right.
4. Use the  or  buttons to select the parameter to configure.
5. The first Setup screen is **S COM** (set communications).
  - a.  to the **ADDR** screen and through the address digits. Use the  or  buttons to select the Modbus address.
  - b.  to the **BAUD** screen. Use the  or  buttons to select the baud rate.
  - c.  to the **PAR** screen. Use the  or  buttons to select the parity.
  - d.  back to the **S COM** screen.
6.  to the **S CT** (Set Current Transducer) screen.
  - a.  to the **CT SZ** screen and through the digits. Use the  or  buttons to select the CT size in amps.
  - b.  back to the **S CT** screen.
7.  to the **S SYS** (Set System) screen.
  - a.  to the **SYSTEM** screen. Use the  or  buttons to select the System Type (see wiring diagrams).
  - b.  back to the **S SYS** screen.
8. (Optional)  to the **S PT** (Set Potential Transformer) screen. If PTs are not used, then skip this step.
  - a.  to the **RATIO** screen and through the digits. Use the  or  buttons to select the Potential Transformer step down ratio.
  - b.  back to the **S PT** screen.
9.  to the **S V** (Set System Voltage) screen.
  - a.  to the **VLL** (or **VLN** if system is 1L-1n) screen and through the digits. Use the  or  buttons to select the Line to Line System Voltage.
  - b.  back to the **S V** screen.
10. Use the  to exit the setup screen and then **SETUP**.
11. Check that the wrench is not displayed on the LCD.
  - a. If the wrench is displayed, use the  or  buttons to find the **ALERT** screen.
  - b.  through the screens to see which alert is on.

For full setup instructions, see the configuration instructions on the following pages.

## Solid State Output

The Series 4000-R meters have one normally open (N.O.) KY Form A output and one normally closed (N.C.) output.\* One is dedicated to energy (Wh), and the other to Alarm. See the Setup section for configuration information.



The solid state pulse outputs are rated for 30 VAC/DC nom.

Maximum load current is 100 mA at 25°C. Derate 0.56mA per °C above 25°C (e.g. 86 mA@50°C).

\* The over-current protective device must be rated for the short circuit current at the connection point.

\*\* All pulse outputs and communication circuits are only intended to be connected to non-hazardous circuits (SELV or Class 2). Do not connect to hazardous voltages.


## User Interface (UI) Menu Abbreviations Defined

The user can set the display mode to either IEC or IEEE notation in the SETUP menu.


Main Menu		
IEC	IEEE	Description
D	D	Demand
MAX	M	Maximum Demand
P	W	Present Real Power
Q	VAR	Present Reactive Power
S	VA	Present Apparent Power
A	A	Amps
UAB, UBC, UAC	VAB, VBC, VAC	Voltage Line to Line
V	VLN	Voltage Line to Neutral
PF	PF	Power Factor
U	VLL	Voltage Line to Line
HZ	HZ	Frequency
KSh	KVAh	Accumulated Apparent Energy
KQh	KVARh	Accumulated Reactive Energy
KPh	KWh	Accumulated Real Energy
PLOSS	PLOSS	Phase Loss
LOWPF	LOWPF	Low Power Factor Error

Main Menu		
IEC	IEEE	Description
F ERR	F ERR	Frequency Error
I OVR	I OVR	Over Current
V OVR	V OVR	Over Voltage
PULSE	PULSE	kWh Pulse Output Overrun (configuration error)
_PHASE	_PHASE	Summary Data for 1, 2, or 3 active phases
ALERT	ALERT	Diagnostic Alert Status
INFO	INFO	Unit Information
MODEL	MODEL	Model Number
OS	OS	Operating System
RS	RS	Reset System
SN	SN	Serial Number
RESET	RESET	Reset Data
PASWD	PASWD	Enter Reset or Setup Password
ENERG	ENERG	Reset Energy Accumulators
DEMND	DEMND	Reset Demand Maximums


## User Interface for Data Configuration



## Alert/Reset Information



## UI for Setup



### Set Communications Parameters:

**ADDR - Modbus Address:** 1 – 247.  
+ increments the selected (blinking) digit.  
- selects the digit to the left.  
**BAUD - Baud Rate:** 1200 – 38400 Baud  
**PAR - Parity:** Odd, Even, None  
+ or – to step through the options.

### Set Current Transducer:

**CT SZ** - CT Size: in Amps. Maximum is 5000 Amps.

### Set System Configuration:

**SYSTEM:** + or – to step through the following System Type options:

System	Reg 130	CTs	Description
<b>3L-1n</b>	40	3	Wye Three Phase: A, B, & C with Neutral (Default).
3L	31	3	Delta Three Phase: A, B & C; no Neutral
2L-1n	12	2	Single Split Phase: A & B with Neutral
2L	11	1	Single Phase: A & B; no Neutral
1L-1n	10	1	Single Phase: A to Neutral

### Set Potential Transformer Ratio:

**RATIO** – Potential transformer step down is RATIO:1. Default is 1:1 (No PT installed). See Install for wiring diagrams. This value must be set before the System Voltage (if used).

### Set System Voltage:

**V LL** – The nominal Line to Line Voltage for the system. This is used by the meter to calculate the theoretical maximum system power, and as the reference voltage for setting the Phase Loss threshold. Maximum is 32000 Volts. For system type 1+N (10), this is a Line to Neutral Voltage, indicated by “V LN”. Note: the meter will reject settings that are not within the meter’s operating range when divided by the PT ratio.


### System Power:

**MX KW** – The theoretical Maximum System Power is calculated by the meter from the System Voltage, CT size, and System Type. Power Factor is assumed to be unity. The value of System Power is used to determine which combinations of pulse weight and duration are valid and will keep up with the maximum power the meter will see. This value is read only.

Note: **Bold** is the Default.

† When leaving this parameter screen using the right button (➡), the display will briefly indicate “SAvEd” to confirm that any changes made have been accepted.

## UI for Setup (cont.)



### Set Phase Loss:

**VOLTS - Phase Loss Voltage:** The fraction of the system voltage below which Phase Loss Alarm is on. For system types with neutral, the Line to Neutral voltage is also calculated and tested. If the System Voltage is 600 and the fraction is set to 0.10, then the Phase Loss threshold will be 60 volts.

**IMBAL - Phase Loss Imbalance:** The fractional difference in Line to Line voltages above which Phase Loss Alarm is on. For system types with neutral, the Line to Neutral voltages are also tested. For system types 1+N (10) and 2 (11), imbalance is not tested.

### Set Pulse:

The System Type, CT size, PT Ratio, and System Voltage must all be configured before setting the Pulse Energy. If any of these parameters are changed, the meter will hunt for a new Pulse Duration, but will not change the Pulse Energy. If it cannot find a solution, the meter will display the wrench, show "ConF" in the ALARM -> PULSE screen, and enable Energy pulse output configuration error bit in the Modbus Diagnostic Alert Bitmap (if equipped).

**Wh/P - Set Pulse Energy:** In Watt Hours (& VAR Hours, if present) per Pulse. When moving down to a smaller energy, the meter will not allow the selection if it cannot find a pulse duration that will allow the pulse output to keep up with Theoretical Maximum System Power (see S\_PWR screen). When moving up to a larger energy, the meter will jump to the first value where it can find a valid solution.

**mS/P - Minimum Pulse Duration Time:** This read only value is set by the meter to the slowest duration (in mS per closure) that will keep up with the Theoretical Maximum System Power. The open time is greater than or equal to the closure time. The maximum Pulses Per Second (PPS) is shown in yellow.

### Set Demand Interval:

**INTRV** - The number of Sub-Intervals (1 to 6) in a Demand Interval. Default is 1 (block demand).

**SEC** - Sub-Interval length in seconds. Default is 900 (15 minutes). Set to 0 for external sync-to-comms (Modbus units only).

### Set Display Units: +/- to switch between:

**IEEE** - VLL VLN W VAR VA Units.

**IEC** - U V P Q S Units.

### Set Passwords:

**SETUP** - The Password to enter the SETUP menu.


**RESET** - The Password to enter the RESET menu.

† When leaving this parameter screen using the right button (➡), the display will briefly indicate "SAvEd" to confirm that any changes made have been accepted.

## RS-485 Communications

### Daisy-chaining Devices to the Power Meter

The RS-485 slave port allows the power meter to be connected in a daisy chain with up to 63 2-wire devices.




### Notes

- The terminal's voltage and current ratings are compliant with the requirements of the EIA RS-485 communications standard.
- The RS-485 transceivers are  $\frac{1}{4}$  unit load or less.
- RS-485+ has a 47 k $\Omega$  pull up to +5V, and RS-485- has a 47 k $\Omega$  pull down to Shield (RS-485 signal ground).
- Wire the RS-485 bus as a daisy chain from device to device, without any stubs. Use 120  $\Omega$  termination resistors at each end of the bus (not included).
- Shield is not internally connected to Earth Ground.
- Connect Shield to Earth Ground somewhere on the RS-485 bus.

### For all terminals:

- When tightening terminals, apply the correct torque: 0.37 to 0.44 ft-lb (0.5-0.6 N·m).
- Use 14-24 gauge (2.1-0.2 mm<sup>2</sup>) wire.



## Standard Modbus Default Settings

Setting	Value	Modbus Register
Setup Password	00000	–
Reset Password	00000	–
System Type	40 (3 + N) Wye	130
CT Primary Ratio (if CTs are not included)	100A	131
CT Secondary Ratio	1V	132
PT Ratio	1:1 (none)	133
System Voltage	600 V L-L	134
Max. Theoretical Power (Analog Output: full scale (20mA or 5V))	104 kW	135
Display Mode	1 (IEEE)	137
Phase Loss	10% of System Voltage (60V), 25% Phase to Phase Imbalance	142, 143
Pulse Energy	1 (kWh/pulse)	144
Demand: number of sub-intervals per interval	1 (block mode)	149
Demand: sub-interval length	900 sec (15 min)	150
Modbus Address	001	–
Modbus Baud Rate	19200 baud	–
Modbus Parity	None	–
Log Read Page	0	158
Logging Configuration Register	0	159
Log Register Pointer 1	1 (Real Energy MSR)	169
Log Register Pointer 2	2 (Real Energy LSR)	170
Log Register Pointer 3	29 (Reactive Energy MSR)	171
Log Register Pointer 4	30 (Reactive Energy LSR)	172
Log Register Pointer 5	37 (Real Demand)	173
Log Register Pointer 6	38 (Reactive Demand)	174
Log Register Pointer 7	39 (Apparent Demand)	175
Log Register Pointer 8	155 (Month/Day)	176
Log Register Pointer 9	156 (Year/Hour)	177
Log Register Pointer 10	157 (Minutes/Seconds)	178

## Modbus Point Map Overview

The Series 4000-R features data outputs such as demand calculations, per phase VA and VAR, and VAh VARh accumulators. For security reasons, configuration and resets on all Series 4000-R models are protected by a user configurable passcode. The meter supports variable CTs and PTs, allowing a much wider range of operation from 90V x 5A up to 32000V x 5000A. To promote this, the meter permits variable scaling of the 16-bit integer registers via the scale registers. The 32-bit floating point registers do not need to be scaled.

Integer registers begin at 001 (0x001). Floats at 257 (0x101). Configuration registers at 129 (0x081). Values not supported in a particular System Type configuration will report QNAN (0x8000 in Integer Registers, 0x7FC00000 in Floating Point Registers).

### Supported Modbus Commands

Note: ID String information varies from model to model. Text shown here is an example.

Command	Description
0x03	Read Holding Registers
0x04	Read Input Registers
0x06	Preset Single Register
0x10	Preset Multiple Registers
0x11	Report ID
	Return string: byte0: address byte1: 0x11 byte2: #bytes following w/out crc byte3: ID byte = 247 byte4: status = 0xFF if the operating system is used; status = 0x00 if the reset system is used bytes5+: ID string = "Leviton Series 4000R Power Meter Full Data Set" - RESET SYSTEM RUNNING RS Version x.xxx" last 2 bytes: CRC
0x2B	Read Device Identification, BASIC implementation (0x00, 0x01 and 0x02 data), Conformity Level 1.
	Object values: 0x01: "Leviton" 0x02: "Series 4000" 0x03: "Vxx.yyy", where xx.yyy is the OS version number (reformatted version of the Modbus register #7001, (Firmware Version, Operating System). If register #7001 == 12345, then the 0x03 data would be "V12.345").

### Legend

The following table lists the addresses assigned to each data point. For floating point format variables, each data point appears twice because two 16-bit addresses are required to hold a 32-bit float value.

R/W	R=read only; R/W=read from either int or float formats, write only to integer format.	
NV	Value is stored in non-volatile memory. The value will still be available if the meter experiences a power loss and reset.	
Format	UInt	Unsigned 16-bit integer.
	SInt	Signed 16-bit integer.
	ULong	Unsigned 32-bit integer; Upper 16-bits (MSR) in lowest-numbered / first listed register (001/002 = MSR/LSR).
	Float	32-bit floating point; Upper 16-bits (MSR) in lowest-numbered / first listed register (257/258 = MSR/LSR). Encoding is per IEEE standard 754 single precision.
Units	Lists the physical units that a register holds.	
Scale Factor	Some Integer values must be multiplied by a constant scale factor (typically a fraction), to be read correctly. This is done to allow integer numbers to represent fractional numbers.	
Range	Defines the limit of the values that a register can contain.	

## Modbus Point Map

S4000-R Register	R/W	NV	Format	Units	Scale	Range	Description
001	R	NV	ULong	kWh	E	0-0xFFFF	Real Energy Consumption (MSR)
002						0-0xFFFF	Real Energy Consumption (LSR)
003	R		UInt	kW	W	0-32767	Total Instantaneous Real Power (3 Phase Total)
004	R		UInt	kVAR	W	0-32767	Total Instantaneous Reactive Power (3 Phase Total)
005	R		UInt	kVA	W	0-32767	Total Instantaneous Apparent Power (3 Phase Total)
006	R		UInt	Ratio	0.0001	0-10000	Total Power Factor (Total KW / Total KVA)
007	R		UInt	Volt	V	0-32767	Voltage, L-L, Average of 3 Phases
008	R		UInt	Volt	V	0-32767	Voltage, L-N, Average of 3 Phases
009	R		UInt	Amp	I	0-32767	Current, Average of 3 Phases
010	R		UInt	kW	W	0-32767	Real Power, Phase A
011	R		UInt	kW	W	0-32767	Real Power, Phase B
012	R		UInt	kW	W	0-32767	Real Power, Phase C
013	R		UInt	Ratio	0.0001	0-10000	Power Factor, Phase A
014	R		UInt	Ratio	0.0001	0-10000	Power Factor, Phase B
015	R		UInt	Ratio	0.0001	0-10000	Power Factor, Phase C
016	R		UInt	Volt	V	0-32767	Voltage, Phase A-B
017	R		UInt	Volt	V	0-32767	Voltage, Phase B-C
018	R		UInt	Volt	V	0-32767	Voltage, Phase A-C
019	R		UInt	Volt	V	0-32767	Voltage, Phase A-N
020	R		UInt	Volt	V	0-32767	Voltage, Phase B-N
021	R		UInt	Volt	V	0-32767	Voltage, Phase C-N
022	R		UInt	Amp	I	0-32767	Current, Instantaneous, Phase A
023	R		UInt	Amp	I	0-32767	Current, Instantaneous, Phase B
024	R		UInt	Amp	I	0-32767	Current, Instantaneous, Phase C
025	R		UInt				Reserved; returns 0x8000 (QNaN)
026	R		UInt	Hz	0.01	4500-6500	Frequency (derived from Phase A)
027	R	NV	ULong	KVAh	E	0-0xFFFF	Apparent Energy Consumption (MSR)
028						0-0xFFFF	Apparent Energy Consumption (LSR)
029	R	NV	ULong	KVARh	E	0-0xFFFF	Reactive Energy Consumption (MSR)
030						0-0xFFFF	Reactive Energy Consumption (LSR)
031	R		UInt	kVA	W	0-32767	Apparent Power, Phase A
032	R		UInt	kVA	W	0-32767	Apparent Power, Phase B
033	R		UInt	kVA	W	0-32767	Apparent Power, Phase C
034	R		UInt	kVAR	W	0-32767	Reactive Power, Phase A
035	R		UInt	kVAR	W	0-32767	Reactive Power, Phase B
036	R		UInt	kVAR	W	0-32767	Reactive Power, Phase C
037	R		UInt	kW	W	0-32767	Total Real Power Present Demand
038	R		UInt	kVAR	W	0-32767	Total Reactive Power Present Demand
039	R		UInt	kVA	W	0-32767	Total Apparent Power Present Demand
040	R	NV	UInt	kW	W	0-32767	Total Real Power Max Demand
041	R	NV	UInt	kVAR	W	0-32767	Total Reactive Power Max Demand
042	R	NV	UInt	kVA	W	0-32767	Total Apparent Power Max Demand

## Modbus Point Map (cont.)

S4000-R Register	R/W	NV	Format	Units	Scale	Range	Description			
043	R	NV	ULong			0-0xFFFF	Pulse Counter 1 (Real Energy)	MSR	Contact Closure Counters. Valid for both Pulse inputs and outputs. Series 4000 counts are shown in (). See register 144 (Energy per Pulse) for the Wh per pulse count. Clear via register 129. Inputs are user defined.	
044								LSR		
045	R	NV	ULong			0-0xFFFF	Pulse Counter 2 (Reactive Energy)	MSR		
046								LSR		
047	R	NV	ULong	kWh	E	0-0xFFFF	Real Energy Consumption Phase A	MSR		Clear via reset register
048								LSR		
049	R	NV	ULong	kWh	E	0-0xFFFF	Real Energy Consumption Phase B	MSR		
050								LSR		
051	R	NV	ULong	kWh	E	0-0xFFFF	Real Energy Consumption Phase C	MSR		
052								LSR		
129	R/W		UInt			N/A	Command Register: - Write 30078 (0x757E) to clear all Energy Accumulators to 0. - Write 21211 (0x52DB) to begin new Demand Sub-Interval calculation cycle. Takes effect at the end of the next 1 second calculation cycle. Write no more frequently than every 10 seconds. - Write 21212 (0x52DC) to reset Max Demand values to Present Demand Values. Takes effect at the end of the next 1 second calculation cycle. Write no more frequently than every 10 seconds. - Write 16498 (0x4072) to Clear Pulse Counters to 0. - Read always returns 0.			
130	R/W	NV	UInt			10, 11, 12, 31, 40	Single Phase: A + N Single Phase: A + B Single Split Phase: A + B + N 3 phase Δ, A + B + C, no N 3 phase Y, A + B + C + N	System Type		
131	R/W	NV	UInt	Amps		20-5000	CT Ratio – Primary	Current Inputs		
132	R	NV	UInt			n/a	Reserved, always returns QNAN			
133	R/W	NV	UInt		100	0.01-320.00	PT Ratio: The meter scales this value by 100 (i.e. entering 200 yields a potential transformer ratio of 2:1). The default is 100 (1.00:1), which is with no PT attached. Set this value before setting the system voltage (below)			
134	R/W	NV	UInt			82-32000	System Voltage: This voltage is line to line, except for system type 10 which is line to neutral. The meter uses this value to calculate the full scale power for the analog outputs and pulse configuration (below), and as full scale for phase loss (register 142). The meter will refuse voltages that are outside the range of 82-660 volts when divided by the PT Ratio (above).			
135	R	NV	UInt	kW	W	1-32767	Theoretical Maximum System Power: This read-only value is the theoretical max. power the meter can expect to see on a service. This value is 100% of scale on the analog output (0-5 VDC or 4-20 mA), if equipped. The meter recalculates this value if the user changes the CT size, system type, or system voltage. This integer value has the same scale as other integer power registers (see register 140 for power scaling).			
136	R		UInt				Reserved, always returns 0			
137	R/W	NV	UInt			0,1	Display Units: 0 = IEC (U, V, P, Q, S), 1 = IEEE (default: VLL, VLN, W, VAR, VA)			

## Modbus Point Map (cont.)

S4000-R Register	R/W	NV	Format	Units	Scale	Range	Description	
138	R		SInt		-4 0.0001		Scale Factor I (Current)	
139	R		SInt		-3 0.001		Scale Factor V (Voltage)	
140	R		SInt		-2 0.01		Scale Factor W (Power)	
141	R		SInt		-1 0.1 0 1.0 1 10.0 2 100.0 3 1000.0 4 10000.0		Scale Factor E (Energy)	
142	R/W	NV	UInt	%		1-99	Phase Loss Voltage Threshold in percent of system voltage (register 134). Default is 10 (%). Any phase (as configured in register 130) that drops below this threshold triggers a Phase Loss alert - i.e. if the System voltage is set to 480 V L-L, the L-N voltage for each phase should be 277 V. When the threshold is set to 10%, if any phase drops more than 10% below 277 V, (less than 249 V), or if any L-L voltage drops more than 10% below 480 V (less than 432 V) the corresponding phase loss alarm bit in register 146 will be true.	
143	R/W	NV	UInt	%		1-99	Phase Loss Imbalance Threshold in Percent. Default is 25% phase to phase difference. For a 3-phase Y (3 + N) system type (40 in register 130), both Line to Neutral and Line to Line voltages are tested. In a 3-phase Δ System type (31 in register 130), only Line to Line voltages are examined. In a single split-phase (2 + N) system type (12 in register 130), just the line to neutral voltage are compared.	
144	R/W	NV	UInt	Wh		10000, 1000, 100, 10	Wh (& VARh, if equipped with FDS) Energy per Pulse Output Contact Closure. If the meter cannot find a pulse duration that will keep up with the max. system power (register 135), it rejects the new value. Try a larger value.	
145	R	NV	UInt	ms		500, 250, 100, 50, 25, 10	Pulse Contact Closure Duration in msec. Read-only. Set to the slowest duration that keeps up with the theoretical max. system power (register 135). The open time ≥ the closure time, so the max. pulse rate (pulses per sec) is the inverse of double the pulse time.	
							Scale Factors	Note: These registers contain a signed integer, which scales the corresponding integer registers. Floating point registers are not scaled. Scaling is recalculated when the meter configuration is changed.
							Phase Loss Output	Note: The phases tested are determined by the System Type.
							kWh Pulse Contacts	Note: The kWh pulse contact can keep up with a maximum power (Watts) of 1800000 x Wh pulse weight ÷ contact closure duration (in msec)

## Modbus Point Map (cont.)

S4000-R Register	R/W	NV	Format	Units	Scale	Range	Description
146	R		UInt				Diagnostic Alert Bitmap. 1 = Active: Bit 0: Phase A Voltage out of range Bit 1: Phase B Voltage out of range Bit 2: Phase C Voltage out of range Bit 3: Phase A Current out of range Bit 4: Phase B Current out of range Bit 5: Phase C Current out of range Bit 6: Frequency out of the range of 45 – 65 Hz OR there is insufficient voltage to determine frequency. Bit 7: Reserved for future use Bit 8: Phase Loss A Bit 9: Phase Loss B Bit 10: Phase Loss C Bit 11: Low Power Factor on A with one or more phases having a PF less than 0.5 due to mis-wiring of phases Bit 12: Low Power Factor on B Bit 13: Low Power Factor on C Bit 14: Energy pulse output overrun error. The pulse outputs are unable to keep up with the total real power (registers 3 and 261/262). To fix, increase the pulse energy register (register 144) and reset the energy accumulators (see reset register 129). Bit 15: Energy pulse output configuration error (present pulse energy setting may not keep up with the theoretical max. system power; see register 135). To fix, increase the pulse energy (register 144).
147	R	NV	UInt			0-32767	Count of Energy Accumulator resets
148	R		UInt				Reserved (returns 0)
149	R/W	NV	UInt			1-6	Number of Sub-Intervals per Demand Interval. Sets the number of sub-intervals that make a single demand interval. For block demand, set this to 1.
150	R/W	NV	UInt	Seconds		0, 10-32767	Sub-Interval Length in seconds. For sync-to-comms, set this to 0 and use the reset register (129) to externally re-start the sub-interval.
151	R/W		UInt			1-32767	Reserved (returns 0)
152	R/W	NV	UInt			0-32767	Power Up Counter.
153	R	NV	UInt			0-32767	Output Configuration. Units have a N.O. (normally open) energy contact and N.C. (normally closed) (N.O. - Form A or N.C. - Form B) Phase Loss contact. While the relay used for the Phase Loss contact is N.C. (contacts are closed when the meter is not powered), closure indicates the presence of an alarm; either loss of phase, when the meter is powered, or loss of power when the meter is not. The contacts are open when the meter is powered and no phase alarm conditions are present. 3rd Output: 0 = RS-485 2 = VAR Pulse
154	R		UInt				Reserved, returns 0
257/258	R	NV	Float	kWh			Real Energy Consumption (clear via reset register)
259/260	R	NV	Float	kWh			Real Energy Consumption (clear via reset register)
261/262	R		Float	kW			Total Instantaneous Real Power
263/264	R		Float	kVAR			Total Instantaneous Reactive Power
265/266	R		Float	kVA			Total Instantaneous Apparent Power
267/268	R		Float	Ratio		0.0-1.0	Total Power Factor (Total KW / Total KVA)
269/270	R		Float	Volt			Voltage, L-L, Average of 3 Phases
271/272	R		Float	Volt			Voltage, L-N, Average of 3 Phases
273/274	R		Float	Amp			Current, Average of 3 Phases
275/276	R		Float	kW			Real Power, Phase A

## Modbus Point Map (cont.)

S4000-R Register	R/W	NV	Format	Units	Scale	Range	Description
277/278	R		Float	kW			Real Power, Phase B
279/280	R		Float	kW			Real Power, Phase C
281/282	R		Float	Ratio		0.0-1.0	Power Factor, Phase A
283/284	R		Float	Ratio		0.0-1.0	Power Factor, Phase B
285/286	R		Float	Ratio		0.0-1.0	Power Factor, Phase C
287/288	R		Float	Volt			Voltage, Phase A-B
289/290	R		Float	Volt			Voltage, Phase B-C
291/292	R		Float	Volt			Voltage, Phase A-C
293/294	R		Float	Volt			Voltage, Phase A-N
295/296	R		Float	Volt			Voltage, Phase B-N
297/298	R		Float	Volt			Voltage, Phase C-N
299/300	R		Float	Amp			Current, Instantaneous, Phase A
301/302	R		Float	Amp			Current, Instantaneous, Phase B
303/304	R		Float	Amp			Current, Instantaneous, Phase C
305/306	R		Float				Reserved, returns 0x7FC00000 (QNaN)
307/308	R		Float	Hz		45.0-65.0	Frequency (derived from Phase A)
309/310	R	NV	Float	kVAh			Apparent Energy Consumption
311/312	R	NV	Float	kVARh			Reactive Energy Consumption
313/314	R		Float	kVA			Apparent Power, Phase A
315/316	R		Float	kVA			Apparent Power, Phase B
317/318	R		Float	kVA			Apparent Power, Phase C
319/320	R		Float	kVAR			Reactive Power, Phase A
321/322	R		Float	kVAR			Reactive Power, Phase B
323/324	R		Float	kVAR			Reactive Power, Phase C
325/326	R		Float	kW			Total Real Power Present Demand
327/328	R		Float	kVAR			Total Reactive Power Present Demand
329/330	R	NV	Float	kVA			Total Apparent Power Present Demand
331/332	R	NV	Float	kW			Total Real Power Max Demand
333/334	R	NV	Float	kVAR			Total Reactive Power Max Demand
335/336	R	NV	Float	kVA			Total Apparent Power Max Demand
337/338*	R		Float			0 - 4294967040	Pulse Counter 1 (Real Energy)
339/340*	R		Float			0 - 4294967040	<p>Contact Closure Counters. Valid for both Pulse inputs and outputs. Counts are shown in (). See register 144 (Energy per Pulse) for the Wh per pulse count. Clear via register 129. Inputs are user defined. These values are derived from the 32 bit integer counter and rolls over to 0 when the integer counters do.</p>
341/342*	R	NV	Float	kWh			Real Energy Consumption, Phase A
343/344*	R	NV	Float	kWh			Real Energy Consumption, Phase B
345/346*	R	NV	Float	kWh			Real Energy Consumption, Phase C

Invalid or Quiet Not A Number (QNaN) conditions are indicated by 0x8000 (negative zero) for 16 bit integers and 0x7FC00000 for 32 bit floating point numbers.

Floating point numbers are encoded per the IEEE 754 32-bit specifications.

## Troubleshooting

Problem	Cause	Solution
The maintenance wrench icon appears in the power meter display.	There is a problem with the inputs to the power meter.	See the Alert sub-menu or the Diagnostic Alert Modbus Register 146
The display is blank after applying control power to the meter.	The meter is not receiving adequate power.	Verify that the meter control power are receiving the required voltage. Verify that the heart icon is blinking. Check the fuse.
The data displayed is inaccurate.	Incorrect setup values	Verify the values entered for power meter setup parameters (CT and PT ratings, system type, etc.). See the Setup section.
	Incorrect voltage inputs	Check power meter voltage input terminals to verify adequate voltage.
	Power meter is wired improperly.	Check all CTs and PTs to verify correct connection to the same service, PT polarity, and adequate powering. See the Wiring Diagrams section for more information.
Cannot communicate with power meter from a remote personal computer.	Power meter address is incorrect.	Verify that the meter is correctly addressed (see Setup section).
	Power meter baud rate is incorrect.	Verify that the baud rate of the meter matches that of all other devices on its communications link (see Setup section).
	Communications lines are improperly connected.	Verify the power meter communications connections (see the Communications section). Verify the terminating resistors are properly installed on both ends of a chain of units. Units in the middle of a chain should not have a terminator. Verify the shield ground is connected between all units.

## China RoHS Compliance Information (EFUP Table)

部件名称	产品中 有毒有害物质或元素的名称及含量 Substances					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
电子线路板	X	0	0	0	0	0
0 = 表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。 X = 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006标准规定的限量要求。						
Z000057-0A						