

Assembly Instruction For 10048

Assembly Instructions

- 1. Rotate the bent tube(A) to the correct position.
- 2. Screw the Loop (B) into the threaded tube (C) and tighten.
- 3. Screw the tube (E) into the threaded tube (D) and tighten.
- 4. Screw the threaded tube (F) into the tube (E) and tighten.
- 5. Screw the threaded tube (I) into the hexnut (G) and tighten with the hexnut (H).
- 6. Fit the tube (J), the cap (K), the cap (L) onto the threaded tube (I) then tighten with the hexnut (M).
- 7. Fit the glass shade (N), the lid (O) onto the threaded tube (I) then tighten with the finial (P).

Electrical Wiring

With wire connectors, connect powercords from outlet box to fixture.

- -Smooth/Black wire to Black wire
- -Ribbed/White wire to White wire
- -Green to Ground

Please consult a qualified Electrician if you are not familiar with electrical wiring.



