PRODUCT SUPPORT BULLETIN # 488

DATE: September, 2008

TO: AUTHORIZED portable electric tool SERVICE STATIONS

factory SERVICE / SALES SUPPORT BRANCH

TOOL(S) \ PRODUCT(S) AFFECTED: 1001-1, 1007-1, 1107-1, 1250-1 D-Handle Drill 6509-20, 6509-22, 6519-22,

6520-21, 6523-21, 6536-21, 6523-55 Orbital Sawzall & 6538-21 Orbital

Super Sawzall

SUBJECT: Service Note: 23-66-0205, 23-66-2490 Switch proper removal or installation of the switch remote dial / electronic assembly terminal/lead(s)

23-66-2490 Switch three terminal remote electronic assembly connection



lifting of brass switch terminal should be kept at a minimum

proper removal of the female Remote Dial Assembly or Remote Electronic Assembly terminal / lead wire of the 23-66-0205 / 23-66-2490 Switch should be done by utilizing the tip of a flat blade screwdriver to 'push' the lead wire terminal(s) off-of the brass male switch terminal(s).

> 23-66-0205 Switch single terminal remote dial assembly connection




lead wire / female terminal laid flat in channel



proper assembly of the female Remote Dial Assembly or Remote Electronic Assembly lead wire(s) terminal to the 23-66-0205 / 23-66-2490 Switch should be done by...

first, laying the female terminal(s) - lead wire assembly(ies) into the channel of the switch - lifting of brass switch terminal should be kept at a minimum



then, utilizing the tip of a flat blade screwdriver to 'push' and fully seat the lead wire female terminal onto the male brass switch terminal.

This bulletin is for informational purposes. PLEASE NOTE ON SERVICE PARTS LIST: 54-08-1094, 54-08-1156, 54-08-1221, 54-08-1301, 54-40-5183, 54-40-5214, 54-40-7510, 54-40-7570, 54-40-7563, 54-40-7583, 54-40-7591, 54-40-7592, 55-40-7600