

Step 2 – Enclosure Kit

Locators				Select NEMA 1 Std	Locators				Select NEMA 12 Std
①	②	⑤	⑥	Width Enclosure Kit	①	②	⑤	⑥	Width Enclosure Kit
17	C	9	B	49EC17BB241108R	17	C	9	N	49EC17BN241108R
17	D	9	B	49EC17BB241108R	17	D	9	N	49EC17BN241108R
17	E	9	B	49EC17BB241108R	17	E	9	N	49EC17BN241108R
17	F	9	B	49EC17BB241108R	17	F	9	N	49EC17BN241108R
17	G	9	B	49EC17CB242008R	17	G	9	N	49EC17CN242008R
17	H	9	B	49EC17CB242008R	17	H	9	N	49EC17CN242008R
17	I	9	B	49EC17FB362412R	17	I	9	N	49EC17FN362412R
17	J	9	B	49EC17FB362412R	17	J	9	N	49EC17FN362412R
18	C	9	B	49EC18DB241108R	18	C	9	N	49EC18DN241108R
18	D	9	B	49EC18DB241108R	18	D	9	N	49EC18DN241108R
18	E	9	B	49EC18DB241108R	18	E	9	N	49EC18DN241108R
18	F	9	B	49EC18DB241108R	18	F	9	N	49EC18DN241108R
18	G	9	B	49EC18DB242008R	18	G	9	N	49EC18DN242008R
18	H	9	B	49EC18DB242008R	18	H	9	N	49EC18DN242008R
18	I	9	B	49EC18DB362412R	18	I	9	N	49EC18DN362412R
18	J	9	B	49EC18EB362412R	18	J	9	N	49EC18EN362412R

Table 2 - Enclosure Kits for Combination Starters

Notes:

- Class 17 enclosure kits include the handle mechanism and the appropriately sized disconnect switch. Class 18 enclosure kits include the handle mechanism but not the circuit breaker.
- Standard width enclosures used for combination starters are sized to accommodate CPTs.

Step 3 – Protective Device Kit

If locator ① is "17", refer to Table 3a. If locator ① is "18", refer to Table 3b.

Locators		Fuse Clip Ratings	Select Fuse Clip Kit		Select Class R Fuse Conversion Kit
①	⑧		Class	Part No.	
17	-	(non-fusible disconnect)			NA
17	10	30A-250V	R	FCRK203	NA
17	11	30A-600A	R	FCRK206	NA
17	12	60A-250V	R	FCRK206	NA
17	13	60A-600A	R	FCRK606	NA
17	14	100A-250V	H	FCK610	SSRK33
17	15	100A-600A	H	FCK610	SSRK33
17	16	200A-250V	H	(2) FCK620	(2) SSRK34
17	17	200A-600A	H	(2) FCK620	(2) SSRK34

Table 3a - Fuse Clip Kits for Fusible Combination Starters

Notes:

- Fuses are not included with fuse clip kits.
- A quantity of two fuse kits and conversion kits are required for 200 amp rated fuse clips due to the enclosure configuration.

Use the three columns below if locator ⑧ is "S" or "T".			Use the two columns below if locator ⑧ is "P" or "G".	
Lo.	Lo.	Select Circuit Breaker Kit	Lo.	Select Circuit Breaker Kit
C	B	ED63A003	A	ED63A003
C	D	ED63A010	B	ED63A010
C	E	ED63A025	C	ED63A025
D	B	ED63A003	D	ED63A025
D	D	ED63A010	E	ED63A030
D	E	ED63A025	F	ED63A030
D	F	ED63A030	G	ED63A050
E	F	ED63A030	H	ED63A040
E	G	ED63A050	J	ED63A050
F	F	ED63A030	K	ED63A050
F	H	ED63A050	L	ED63A100
G	H	ED63A050	M	ED63A050
G	J	ED63A100	N	ED63A100
H	J	ED63A050	P	ED63A125
H	K	ED63A100	R	FXD63A150L
I	L	ED63A125		
J	M	FXD63A150L		

Table 3b - Circuit Breaker Kits for Combination Starters

Circuit breakers are magnetic trip only.