#### Q U O I Z E L 6 CORPORATE PARKWAY GOOSE CREEK, SC. 29445 www.quoizel.com

Quoizel, Inc. 6 Corporate Parkway Goose Creek, SC 29445

Customer Service Phone 631.273.2700 Fax 631.231.7102 www.quoizel.com

# Assembly Instruction Sheet #IS-CKME1723T For Style CKME1723T

Tools Required: None

**Bulb Recommended:** (1) Medium Base 150W (3-way) Maximum

Estimated Assembly Time: 15-20 minutes

**Preparation:** Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.



### **Warnings and Cautions**


Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

## **Package Contents**

| Part | Description | Quantity |
|------|-------------|----------|
| Α    | Harp        | 1 pc.    |
| В    | Base        | 1 pc.    |
| С    | Finial      | 1 pc.    |
| D    | Shade       | 1 pc.    |




Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at <a href="https://www.quoizel.com">www.quoizel.com</a>
© 2013 Quoizel Inc.

1 of 3




2 S1594TN SHADE TAN FABRIC 18"D 1 2of3

Q U O I Z E L 6 CORPORATE PARKWAY GOOSE CREEK, SC. 29445 www.quoizel.com

## Assembly Instruction Sheet #IS-CKME1723T For Style CKME1723T


### STEP 1 - Install the Harp

A. Install the Harp (A) by pressing the ends of the Harp into the Harp Clips on the Base (B) as shown.



#### STEP 2 - Attach Shade


A. Place the Shade (D) onto the top end of the Harp (A). Secure by threading the Finial (C) onto the Harp (A). Hand tighten until snug.



### STEP 3 - Install Bulb

- A. This fixture uses standard bulb with medium base. Maximum 150 watts (3-way).
- B. Insert bulb and screw snugly into place.

Your fixture is now assembled and ready to use. Enjoy!



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at <a href="https://www.quoizel.com">www.quoizel.com</a>

December 2013

3of3