

INSTALLATION INSTRUCTIONS

Avante Compact Fluorescent Lamp

for

Edwin Gaynor Lampholder

Upon receipt, thoroughly inspect for any freight damage which should be brought to the attention of the delivery carrier. Compare the catalog description listed on the packing slip with the label on the carton to ensure you have received the correct merchandise.



IMPORTANT SAFETY INFORMATION For Your Protection, Read Carefully

WARNING - Risk of fire. Do not install insulation within 3 inches of fixture sides or wiring compartment, nor above the fixture in such a manner as to entrap heat.

1. Electric current can cause painful shock or serious injury unless handled properly. For your safety, always remember the following:

- Turn off the power supply.
- Ground the fixture to avoid potential electrical shocks.
- Do not handle an energized fixture or energize any fixture with wet hands, when standing on a wet or damp surface, or in water.
- Double check all electrical connections to be sure they are tight and correct.

2. Specific safety information concerning lamps:

- Match wattage of fixture and lamp exactly.
- Do not remove or insert lamp when power is on.
- Do not scratch glass or subject lamp to undue pressure as either may cause lamp breakage.
- Protect operating lamp from sources of moisture.



Figure 1



Figure 2



Figure 3



Figure 4

Installation:

1. Insert the lamp pins of the compact fluorescent lamp (CF40, CF50 or CF55) into the lampholder with lamp angled away from the fixture. Engage locking notch on the lamp base onto the hook in the hooded shroud of the Edwin Gaynor lampholder. See Figure 1 for example.
2. While supporting the lamp base with one hand, rotate the lamp towards the fixture with the other hand. As the lamp is rotated towards the fixture, snap the lamp base into the lampholder securely. See Figure 2 for example.
3. Engage the lamp support clamp with the free end of the lamp as shown in Figure 3.
4. Lamped fixtures are shipped from the factory with a lamp clamp locking device that snaps over the lamp support clamp as shown in Figure 4. When re-lamping the fixture, pry out on the lamp clamp lock on one side and remove. It is not necessary to replace the lamp clamp lock after replacing the lamps.