# LEVITON
*Building a Connected World*

## Instructions for Use

# QuickPort® Category 3 Snap-in Connector



Pin Number

Color Code for T568A and B Wiring

**1**



**2**



**3**



**4**

## QuickPort® Category 3 Snap-In Connector

### DESCRIPTION
Leviton's QuickPort Category 3 Snap-In Connectors feature dual-color wiring labels for T568A and T568B wiring configurations; these connectors offer dual-flexibility in a single connector.

### INSTALLATION
1. Remove jacket from cable.
2. Check jack termination label (located on sides of jack) for wiring standard and associated color codes. The label also includes jack pin numbers. **(Figure 1)**
3. Route the wires for termination as shown in **Figure 2**.
4. Using a 110-style punchdown tool, seat the wires into the IDC slots. With the cutting edge of the tool to the outside, trim the excess wire flush with the jack body. **(Figure 3)**
5. Place the cap over the termination wires for secure connection and added strain relief. **(Figure 4)**
6. Insert jack assembly into platform or wallplate. Note the "UP" position of the jack.

## IMPORTANT INSTRUCTIONS
1. Read and understand all instructions. Follow all warnings and instructions marked on the product.
2. Do not use this product near water—e.g., near a tub, wash basin, kitchen sink or laundry tub, in a wet basement, or near a swimming pool.
3. Never push objects of any kind into this product through openings, as they may touch dangerous voltages.
4. SAVE THESE INSTRUCTIONS.

## SAFETY INFORMATION
1. Never install communications wiring or components during a lightning storm.
2. Never install communications components in wet locations unless the components are designed specifically for use in wet locations.
3. Never touch uninsulated wires or terminals unless the wiring has been disconnected at the network interface.
4. Use caution when installing or modifying communications wiring or components.
5. To prevent electrical shock, each opening must be filled with a module.

DI-C00-41108-00A

# LEVITON