INSTRUCTIONS:

Models EN-12100-R-AR and EN-12150-R-AR 100/150 Watt 12 Volt Electronic Transformers

CAUTION – TO REDUCE RISK OF FIRE AND ELECTRICAL SHOCK

- Always turn off power at main switch prior to installation.
- Intended for installation by a qualified electrician.
- System is intended for installation in accordance with National Electric Code, and local regulations. Consult with local inspector to assure compliance.

	1	1		
	EN-12100-R-AR	EN-12150-R-AR		
MAX LOAD	100W	150W		
MIN LOAD	35W	50W		
INPUT VOLTAGE	120V	120V		
INPUT CURRENT	0.83A	1.3A		
OUTPUT VOLTAGE	11.6V	11.6V		
MAX CASE TEMP	90° C (194°F)			
AMBIENT TEMP	-20° C ~ +50° C (-4°F ~ 122°F)			

FEATURES:

- Radio disturbance suppression.
- Electronic short circuit protection with auto reset.
- Overload protection with auto reset.
- Soft start delay to preserve bulb life, for use with tungsten filament lamps.
- Dimmable with electronic dimmer switches.

INSTALLATION:

- 1. Use #14 AWG (minimum) wire for output wire.
- 2. Transformers must be installed away from heat sources and accessible for service.
- 3. Unit is a UL listed component for replacement installation, requires enclosure.
- 4. Dimmer switches install on the primary side.
- 5. Connect building wires to like color transformer wires with wire nuts. Building ground wire may be green or un-insulated, and attaches to ground screw on enclosure.
- 6. Connect out put wires from transformer to fixture wires with wire nuts. Wires to fixtures may be chain wired or "home run" wired back to the transformer. High frequency output is only readable with a true RMS meter with sufficient range capability.

MAXIMUM LENGTH / VOLTAGE DROP GUIDELINE							
WIRE SIZE	LOAD						
	35 W	50 W	60 W	100 W	150 W		
14 GAUGE	21 FT	19 FT	15 FT	14	12		
12 GAUGE	28 FT	25 FT	21 FT	19	17		





 615 South Street, Garden City, NY 11530

 LIGHTING

 Tel: (516) 515-5000

 Fax: (516) 516-5050

168 Brea Canyon Road, City of Industry, CA 91789 Tel: (909) 468-1848 Fax: (909) 468-9958